



SEE DETAIL 1

DIMENSION FROM EDGE OF SILL TO EDGE OF ACTUATOR SETUP IS 7.875.

* ALL LOUVER PANELS SHOWN ARE SINGLE LINKAGE. IF DOUBLE LINKAGE PER LOUVER PANEL IS REQUIRED, ADDITIONAL QUANTITIES OF AFFECTED ITEMS WILL BE PROVIDED FOR EACH SET OF LINKAGE.

ITEM	PART DESCRIPTION	DRAWING NUMBER	QUANTITY PER	TOTAL
			# OF PANELS 2 x 2	
A	JACKSHAFT STAND W/ BEARING	287B3-STD	5	
B	REMOVABLE LINKAGE ARM TYPE 'S'	18142-STD	8	
C	UNI-CLAMP NO. UM5016-131	25724-STD	3	
D	1" DIA. JACKSHAFT TUBE	25722-STD	2	
E	1/4"-20 x 3' LG HEX HEAD	-	6	
F	5/16" DIA SWIVEL	A23749	8	
G	5/16" DIA. PLATED STEEL CONNECTING ROD	-	4	
H	PLATED STEEL MOUNTING SCREWS (#14 x 3/4" LG)	-	12	
J	HONEYWELL ACTUATOR MOUNT	31034-STD	1	
J				
K				
L	LINKAGE INTERCONNECT	32929-STD	2	
M	E-CLIP	-	4	

REVISION	DATE	BY	APPD
abi. air balance, inc. A MESTEK COMPANY 7301 INTERNATIONAL DRIVE HOLLAND, OHIO Phone (419) 885-5000 Fax (419) 885-1375 MULTI-HIGHxWIDE PANEL W/ ON BLADE LINKAGE			
CRD BY	APPD BY		
DRN BY	JMC	DWG. NO.	REV.
DATE	02/27/81	32771-2-STD	

BELIMO ACTUATOR

2-712771-2