

# **KN2/KN4/rAy LonWorks Configuration**

## **Revision History**

---

### **Version 2.30 (12/08/2011)**

Requires control firmware version 2.70 or greater.

- 1) Added Boiler##\_LocalOverride.
- 2) Added Read/Write DHW Setpoint
- 3) Added Boiler Status4 Flags for the Master/Boiler 01 and all Members.
- 4) Added Boiler DHW Temperatures for the Master/Boiler 01 and all Members.
- 5) Added Boiler Modulation for the Master/Boiler 01 and all Members.
- 6) Added OperatingSetpoint for the Master/Boiler 01.

### **Version 2.23 (6/6/2011)**

- 1) Fixed a bug with Runtime and Cycles. Needed to swap upper and lower 16-bit words.
- 2) Added notes to output variable section (nvo) that describes how to modify the configuration to work with Trane controls that require implicit addressing with update notifications.

### **Version 2.22**

- 1) Skipped to stay in sync with other products

### **Version 2.21**

- 2) Added Modbus Poll Delay = 300ms to limit polling rate to the speed that our control can handle.

### **Version 2.20**

- 1) Added (published) Boiler Supply and Return Temperature datapoints.